



# Tw:st

## TECHNICAL SPECIFICATIONS AND SETUP INSTRUCTIONS

- Original Tw:st Banner ◀
- Tw:st 3D Banner
- Easi-link
- Flexi link



*exhibiting with = twist*

### Elements

- 3x 700mm aluminium upright sections (3x female/male plugs & light cap)
- 1x Base (including rubber grommet)
- 1x Light
- 1x Transformer
- 1x Original Tw:st Graphic

The Original Tw:st banner takes approximately 90 seconds to erect including light and graphic.

Place base correct way up as illustrated. Take bottom section of upright and push firmly into black base fitting. (The bottom section has one open end). **Please ensure that the bottom section is pushed fully into the base fitting.**

Continue to build the upright by twisting the middle section onto the bottom, then twisting top section onto the middle. If you prefer, before placing the top section onto the upright you can plug the light into the top holes of the cap, however this can be done at any stage of assembly.

Holding the top of the graphic, place the tensioning strip on the groove in the light cap, then place the two locating pins situated on the bottom mounting strip and slide into place; if needed insert rubber grommet to hold in place. Move the tensioning strip so it sits central on the caps groove.

Do not move the banner by holding the upright in a horizontal position.

If you have not fitted your light already, take the light and plug into holes situated on top of the cap. **Please take care when adjusting the light and only move it by holding the black moulded handle – not the light itself.**

Next, take your transformer and plug the two jack plugs into the side sockets on the cap. [Within the extrusion design there is a channel for the cable where needed]. Plug transformer into mains.

Your banner is now finished.

